



Firmware Update Guide

Wingman SD




This document describes how to update the firmware of Brook Wingman SD.


- ⚠ **NOTE** : The update must be done on a PC; it cannot be done on a console.
- ⚠ **NOTE** : Make sure your PC is connected to the internet.
- ⚠ **NOTE** : You may try to disable antivirus, or run the program as administrator.


STEP 1 Download the update file from “**Download**” on Brook website:

www.brookaccessory.com




STEP 2 Hold down the converter button and plug it to PC



STEP 3 Click START**STEP 4** **DO NOT** disconnect during the update process

STEP 5 The following screen will be shown when the update has successfully finished.



STEP 6 In case firmware update fails, the following screen will show, and please try to redo the setup from the beginning.

We recommend that you visit our website www.brookaccessory.com and download the update file again before restarting the update.

