



Firmware Update Guide

Wingman SNES




This document describes how to update the firmware of Brook Wingman SNES.

- ⚠ **NOTE** : The update must be done on a PC; it cannot be done on a console.
- ⚠ **NOTE** : Make sure your PC is connected to the internet.
- ⚠ **NOTE** : You may try to disable antivirus, or run the program as administrator.


STEP 1 Download the update file from “**Download**” on Brook website:

www.brookaccessory.com

Unzip it, and execute the program



STEP 2 Hold down the button on the converter and plug it into PC.



STEP 3 Check if the firmware version of your converter is the latest.

If it's the latest, you don't need to do firmware update.

If not, click START to update.

Latest version
on the server

Firmware
Update

The latest version :
V1.2.8

Current version
on the converter

Current Version : V1.2.8


step. 1


step. 2

Press and hold the button, then connect device to the PC.

START

STEP 4 **DO NOT** disconnect during the update process



STEP 5 Update completed.**STEP 6** In case firmware update fails, the following screen will show, and please try to redo the setup from the beginning.

You can visit our website www.brookaccessory.com and download the update file again before restarting the update.

