Firmware Update Guide

Xbox 360/Xbox ONE to PS4 Super Converter

This document describes how to update the firmware of Brook Super Converter.

NOTE   The update must be done on a PC; it cannot be done on a console.

NOTE   Operate it on desktop PC. For laptop, please connect your laptop to power supply.

NOTE   Do it on Windows 7(and above) or Mac.

NOTE   No need to install USB Driver for the firmware update.

NOTE   Don't connect your controller/stick when doing update

NOTE   It may take some time for the firmware to run in different PC/system.

NOTE   Disable antivirus when operating.

NOTE   If there's any problem during update, please try to

1. Disconnect, reconnect and retry
2. Switch another USB port and retry
3. Use another PC and retry
4. Restart PC and retry
5. Restart firmware and retry
6. Make sure you download the correct file
7. If you have installed ZeroPlus Driver before, remove it and retry

**STEP 1**   Download the latest update file from Brook's website:

http://www.brookaccessory.com/download/

STEP 2   There are two versions,

Normal Version   **TE Version**

XBOX360XBOX
ONEtoPS4_V22_
201609

XBOX360XBOX
ONEtoPS4_TE_V
22_201609

STEP 3   Choose the version you want and run it.

STEP 4   Plug converter into USB port on PC

Normal Mode: Blue LED

TE Mode: Purple LED

※**Note: Don't use USB hub when plugging into PC**

STEP 5   Tick "Controller Compatibility Update" and click "START" button.

STEP 6   DO NOT remove the converter while updating

STEP 7   Update complete, click "FINISH" to close.

Normal Mode: Blue LED

TE Mode: Purple LED

Normal Mode

TE Mode